



LowandMean.com  
928.680.6660

KAWASAKI MEAN STREAK **SHAFT DRIVE COVER**

Part # LM-01-300

## **INSTRUCTIONS**

LM-01-300 includes:	<b>WARNING:</b> Do not install with the motor warm. This is an install at your own risk. If you are not capable to install successfully then we highly suggest you take this item to a professional shop. Always check the fit before sending this product off to paint.
1 Rubber washer	

### **Suggestions for install:**

- 1) First, you must support the bike so you can remove the shock on the shaft drive side.
- 2) Next, remove the shock.
- 3) Slide the SDC into place, with the shock mount going through the 1" hole in the SDC.
- 4) Install the supplied rubber washer so it sits between the SDC and the shock.
- 5) Last, re-install the shock
- 6) Check fit and firmness after your first ride of showing off your **Nice bike™**.



Please contact our Tech support if you have any issues or questions on install  
Sales@LowandMean.com or 928-680-6660

© 2006-2014 Low and Mean L.L.C.™, All rights reserved.