

Contact Tech Support if you have any issues or questions  
[Techsupport@LowandMean.com](mailto:Techsupport@LowandMean.com) or 928-680-6660  
 © 2006-2014 Low and Mean L.L.C.™, All rights reserved.



## SCREEN INSTALLATION

### INSTRUCTIONS

Honey Comb Screen and/or  
Cage Screen



QR Code will direct you to the Low and Mean Install Video.



**WARNING:** We highly recommend using a motorcycle jack/lift for this install to stabilize the motorcycle. Do not install this item when the motor is warm. This is an install at your own risk. If you are not capable of installing this successfully then we highly suggest you take this item to a professional shop. **Always check your work after your first ride.**

### READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

These are general instructions for installing the Honeycomb and/or Cage Screen. Various Low and Mean products offer this as an add-on. Installing a Honeycomb and/or Cage Screen can be easily accomplished if you read over these instructions before starting. Kits include the Screen, Super Glue, Accelerator Spray and double-sided tape.

- 1 Place Screen in position to make sure it fits and lines up correctly. Use double-sided tape to hold screen in place. Fig. 1.
- 2 Apply one drop of super glue then spray with the accelerator spray. Glue should dry almost immediately. Check to make sure the screen is in the proper position. Fig 2.
- 3 Apply super glue to the screen - moving left and right from the initial point. After applying glue in two or three more spots - Spray with the accelerator spray. Fig. 3.
- 4 Carefully apply glue around the rest of the Screen, stop and spray on accelerator spray every few drops. Repeat until you have applied super glue & accelerator spray around the entire screen. Fig. 4

Fig. 1



Fig. 2



Fig. 3



Fig. 4

