



LowandMean.com
928.680.6660

KAWASAKI MEAN STREAK HONEY COMB SCREENS

Part # LM-01-100S

INSTRUCTIONS

LM-01-100S includes:	WARNING: Do not install with the motor warm. This is an install at your own risk. If you are not capable to install successfully then we highly suggest you take this item to a professional shop. Always check the fit before sending this product off to paint.
1 Low & Mean glue	

Suggestions for install:

- 1) First, Install LM-01-100 (Chin Radiator Shroud) to check fit (see product instructions).
- 2) Install the Honey Comb screen to inside Chin Radiator Shroud by placing the CRS on a stable surface.
- 3) The Honey Comb screen has two sides, make sure the smooth side is facing out and also pay attention to the direction of the Honey Comb pattern matches top and bottom.
- 4) It's important to bend the screen to the shape of inside of the CRS.
- 5) When using the Low & Mean glue be careful not to let the glue run onto the front side of the CRS. Start by gluing a little at a time.
- 6) Gluing Honey Comb screen completely. Check the fit to the bike before you send the CRS out for paint.

Check fit and firmness after your first ride of showing off your *Nice bike™*.



Please contact our Tech support if you have any issues or questions on install
Techsupport@LowandMean.com or 928-680-6660