



QR Code takes you directly to the LM Install Video.

Let us know how your installation went. Send an email to Sales@LowandMean.com

By doing this your name will be entered into our monthly drawing for a Low and Mean T-shirt.

- Supplied with Kit:
Low and Mean Chin Shroud
5 Flat Head Bolts
5 Rubber Washers
5 Aluminum Collars

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

- 1 Remove the horn, radiator screen and the rectifier cover. Fig. 1 & 2 Also remove the top center bolt. Fig. 3
- 2 You can reinstall the stock screen with the New Chin Radiator Shroud, or the optional Honey Comb Screen to the back side of the Chin Radiator Shroud.
- 3 Install the new hardware to the 5 mounting points on the Chin Radiator Shroud Fig.4 Start by putting the bolt through the front of the Chin Radiator Shroud, then install the rubber washer on the back side, and then the aluminum collar. This way the rubber washer sits between the fiberglass and the Aluminum collar. Fig. 4
- 4 Before you install the Chin Radiator Shroud, it's important to check the mounting tabs on the sides of the radiator so they are straight with the face of the radiator. If they are bent out then the bolts will not go in straight. You will keep the stock "mountain clips" to install the New Shroud. We suggest adding a small amount of Loctite to the mounting clips threaded nuts.

- 7 With all the hardware in place, position the Chin Radiator Shroud up to the neck of the frame and around the key lock, then position the top bolt with a few turns. Work your way down to the other hardware making sure the aluminum collars do not fall off. You'll have to look behind the part as you're installing the hardware to see the bolts enter the mounting areas.
- 8 Make sure all the hardware is installed with a few turns on each bolt. Then continue to evenly tighten each bolt, do not over tighten the hardware. Should only put a little force before it feels tight. Do not over tighten to the point the fiberglass cracks.
- 9 The fit of this product will be tight to the frame, if any area of the Chin Radiator Shroud is not fitting the frame and has more than ¼ gap then you might have to do a little trimming. 8) Relocating the horn can be positioned under the tank on the exhaust side: See Fig. 5 You'll need to bend the horn bracket tab on the end to install with the stock hardware. After the horn fits, remove and reinstall with the horn wires.



Fig.1



Fig.2



Fig.3



Fig.4



Fig.5