



LowandMean.com

928-680-6660

Honda Fury Rear fender

Part # LM-02F-210

## INSTRUCTIONS

LM-02F-210 includes:		<b>WARNING:</b> We highly recommend installing this product before painting. Do not install this product with the engine warm or the battery connected. This is an install at your own risk. If you feel you are not capable of installing successfully, we highly suggest you take this item to a professional shop.
3	Rubber washers	
8	Plastic pop rivets	
3	Small Zip ties	

### Suggestions for install:

- 1) Make sure the bike is stable before removing the stock parts.
- 2) Remove the seat, stock rear fender, and tail light support bracket.
- 3) Remove the mud flaps and install them on the Low and Mean fender using the supplied plastic pop rivets.
- 4) You will need to disconnect one area of the wire harness from the frame. Reconnect it with a zip tie. (See Figure 1.1)
- 5) Place the three supplied rubber washers on the frame supports where the fender would mount to the frame. (See Figure 1.2)
- 6) Install the LM rear fender by positioning the mud flaps first. (See Figure 1.3)
- 7) Line up the holes in the fender to the holes in the frame and reinstall the front plastic clips.
- 8) Install the seat bolts and the rear passenger seat bolt. The passenger seat hole is optional when ordering.
- 9) When you connect the LED light and route the wire, be careful not to pinch the wire between the fender and the frame.

Always check your work before and after your first few rides.

Figure 1.1



Figure 1.2



Figure 1.3



Send us pictures of your Fury with our products installed to be shown on our social media!

[Sales@LowandMean.com](mailto:Sales@LowandMean.com) or 928-680-6660

Low and Mean L.L.C. ™, All rights reserved.