



LowandMean.com

928.680.6660

HONDA FURY REAR FENDER COVERS

Part # LM- 02F-215

INSTRUCTIONS

LM- 02F-215 includes:

1	Polished bolt
1	6mm nut
1	Small washer
1	Rubber washer

WARNING: We highly recommend installing this product before painting. Please do not install this product with the motor warm or the battery connected. This is an install at your own risk. If you are not capable to install successfully then we highly suggest you take this item to a professional shop.

Suggestions for install:

- 1)** To install this product you of course must have the LM Rear fender and the 3 slots and 5 holes cut on the fender. There are 4 holes for a license plate, which can be filled with silicone or left open, but they are there if you decide to add the license plate at a later time. (See figure 1.1)
- 2)** Make sure your LED light is in place before you attach the cover.
- 3)** Position the cover by sliding the three tabs into the three slots under the LED light. (See figure 1.2)
- 4)** Now position the cover so the bottom hole lines up so you can insert the polished bolt flat head supplied bolt.
- 5)** It's important to make sure the product fits snug to the fender for the proper fit. If need be feel free to adjust the cover with a small file.
- 6)** Once in place, use loctite on the bolt and small amounts of silicone on the inside of the fender where the Rear Cover tabs come through. (See Figure 1.3)

Note: The smooth cover is unique blank canvas to add your style. Things like integrating a LED are to sit behind the cover and shine out. More brake lights and or turn signals can be added behind the cover for a more custom look.

Figure 1.1



Figure 1.2



Figure 1.3



Please send us a picture of your new product on your *Nice bike*™.

Please contact our Tech support if you have any issues or questions about install

Techsupport@LowandMean.com or 928-680-6660

© 2006-2015 Low and Mean L.L.C.™, All rights reserved.