



LowandMean.com

928.680.6660

HONDA FURY CHROME AXLE COVERS

Part # LM-02F-335

INSTRUCTIONS

LM-02F-335 includes:		WARNING: COMPLETELY READ INSTRUCTIONS BEFORE INSTALLING! We highly recommend using a motorcycle jack/lift for this install to stabilize the motorcycle. Do not install this item when the motor is warm. This is an install at your own risk. If you are not capable to install successfully then we highly suggest you take this item to a professional shop.
5	Chrome covers	
1	Adhesive	
1	Spray accelerator	

Suggestions for install:

- 1) Start off by putting your motorcycle on a stable lift so the motorcycle is level and safe to work on.
- 2) Layout which chrome cover fits which axle bolt.
- 3) Before starting be careful not to get the Adhesive on your hands or your motorcycle. It's also possible to glue the protective tape that is around the chrome cover, to the chrome covers. Please take your time use small amounts of adhesive at a time. The accelerator will instantly harden the adhesive.
- 4) We started with the front axle on the exhaust side. Use the supplied adhesive on the edge and inside of the chrome cover. Push the cover in place and spray the accelerator. Remove the tape when the cover is secure.
- 5) On the other side of the front wheel (Clutch side) this cover should have double sided tape on the inside, peel off the one side and apply the adhesive glue and install with pressure and accelerator spray. Remove the tape when the cover is secure.
- 6) Moving to the rear axle on the exhaust side; You'll use the largest cover for the axle nut and the smallest cover over the black bolt. See Fig.2 Apply the adhesive and accelerator spray as you did on the other two covers. Remove the tape when the cover is secure.
- 7) On the shaft drive side; the Chrome cover is more of a plug because of the axle design. Continue to use the adhesive around the edges to properly attach the chrome cover/plug into the axle. Remove the tape when the cover is secure.
- 8) It's suggested to double check all these chrome covers before your first few rides, if they come loose then reapply the adhesive, when done correctly they will not come off from normal riding.



Please send us a picture of your **Nice bike™**.

Please contact our Tech support if you have any issues or questions about install

Techsupport@LowandMean.com or 928.680.6660

© 2006-2014 Low and Mean L.L.C.™, All rights reserved.