



LowandMean.com
928.680.6660

YAMAHA RAIDER FULL WRAP FRONT FENDER

Part#LM-04-205R

INSTRUCTIONS

LM-04-205R includes:		WARNING: Do not install with the motor warm. This is an install at your own risk. If you are not capable to install successfully then we highly suggest you take this item to a professional shop. Always check the fit before sending this product off to paint.
1	LOCTITE	
6	Rubber washers	

Suggestions for install:

- 1) Make sure your bike is stable either on the kick stand or a bike stand before you begin.
- 2) Remove the current front fender that is on your bike.
- 3) You will use your stock hardware to attach the new Full wrap front fender.
- 4) Start by installing the stock bolts from the inside out and slide the supplied rubber washer on the bolt so it will sit between the fender and the fork mounts.
- 5) Once you have the hardware and rubber washers installed on the new Full wrap front fender, slide the fender in place, lining all the hardware up to the fork mounts.
- 6) USE LOCKTITE on final install; evenly snug each bolt until the fender sits in place. You might have to tilt the fender forward or back to fit in the desired location.
- 7) Once the fender is in place and snug, evenly tighten down each bolt.
- 8) If you notice the fender is closer to the tire on one side, then loosen the bolts, hold the fender out with your hand and retighten.
- 9) Check fit and firmness after your first ride of showing off your **Nice bike™**.



Please contact our Tech support if you have any issues or questions about install.

Techsupport@LowandMean.com or 928-680-6660

© 2006-2015 Low and Mean L.L.C.™, All rights reserved.