



Scan the QR code to the left to be directed to the **How To Video** by Low and Mean

Let us know how your installation went. Send an email to techsupport@lowandmean.com



Parts Included:

Highway Peg
Bolt, Nut & Washer

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

- 1 Make sure your motorcycle is very stable and not warm/hot from running.
- 2 Remove the long front engine mount bolt. Fig. 1 (17mm hex head bolt)
- 3 Slide bolt out, you may need to use a rubber mallet to tap this bolt out. Fig. 2
- 4 Position Low and Mean Highway Peg between frame and engine.
- 5 Use bolt supplied and slide it back through. Fig. 3
- 6 If needed tap with a rubber mallet to help get the bolt through the mount or use your socket wrench to thread it thru.
- 7 Use the supplied washer and nut to attach the Highway Peg to your Star Bolt. Fig. 4
- 8 Tighten to manufacturer's torque spec's.

Fig. 1



Fig. 2



Fig. 3



Fig. 4

