



Scan the QR code to the left to be directed to the **How To Video** by Low and Mean

Let us know how your installation went. Send an email to techsupport@lowandmean.com

Part # ending in - 400 Stryker Low Seat Pan

Part # ending in - 410 - Stryker Low Seat Pan with Foam

Part # ending in - 420 - Complete Stryker Low Seat

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

- 1 Insert key in left side lock and turn - Lift and Remove Seat Fig. 1
- 2 Remove tool tray and tool kit from top of battery along with any other parts that could get in the way of the new Low and Mean Seat. Fig. 2
- 3 Apply Velcro to back of seat and to the fender. Fig. 3
- 4 Slide New Low and Mean Seat into place and press down. Fig. 4

Fig. 1



Fig. 2



Fig. 3



Fig. 4



Part Number LM-04S - 420

Part Number LM-04S- 410



Part Number LM-04S - 400