

Installation video not available.



Filter not included

Parts Included:

Honeycomb Screen
x3 Screws

Tool Required:

Phillips Screwdriver

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

- 1 Take your K&N Filter with the logo on the chrome cap facing up.
- 2 Slide the bent screen over the filter with the overlap on the right and bend into place. The top will overlap the bottom.
- 3 Coming from the right side of the logo, screw the provided three screws through both sides of the mesh and into the filter.
Note: This will not affect filter performance. You may silicone the screws into place for a better seal.

