LM-04B-300



www.lowandmean.com

Scan the QR code to the left to be directed to the *How To Video* by Low and Mean

Let us know how your installation went. Send an email to techsupport@lowandmean.com



## **Parts Included:**

Front Rocker Box Left Side Rocker Box Right Side Rocker Box Loctite

## READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

## Required to watch Install Video to ensure a smooth install.

- Remove cylinder cover on right side remove 2 bolts and slide cover out.
- Remove 2 bolts on left side cover slide cover up to get this cover un hooked so you can slide it out. Remove 2 bolts that are holding on a wire heat shield that will also come off that is under the cover.
- 3 Remove seat, remove 2 bolts holding gas tank and slide gas tank back 2 to 3 inches. Fig. 5
- 4 Remove left front cover (2 bolts) then slide cover straight out.
- 5 Remove bracket that was holding the cover 2 bolts.
- Remove rubber cover (right in front of gas tank on left side) and bracket holding wire harness in place. Fig. 1
- 7 Remove right front cover 2 bolts then slide cover out.

- 8 Remove bracket that was holding the cover 2 bolts.
- Remove rubber grommets and chrome spacers from stock cylinder
- 9 cover and insert into openings on your new Low and Mean Rocker Boxes.
- To minimize scratching your motorcycle or the Rocker Box place tape on various rub points. Fig. 2
- Position Low and Mean front Rocker Box at a 90 degree angle on the left side of the motorcycle Require that you watch the install video to see how to get this new one piece front cover in place. Fig. 3
- Slide bracket up and under front Rocker Box and bolt back into place using loctite. Do this on both the left and right side. Fig. 4
- 13 Install new Low and Mean Rocker Box on back right cylinder.
- 14 Install new Low and Mean Rocker Box on back left cylinder.
- 15 Slide gas tank back into place reinstall 2 bolts to hold into place. Fig. 5
- 16 Reinstall seat.









